



Installation:

- 1. Measure door width and height.**
- 2. If needed, shorten.**
- 3. Across top, press the short strip on door stop so the vinyl presses firmly against the door when closed.**
- 4. On sides, press long strips on door stop so the vinyl presses firmly against the door when closed.**
- 5. Mark hole locations, then drill and screw into place.**
- 6. Make sure top strip fits snugly against side strips.**
- 7. Holes are slotted to permit adjustment.**

Instalación:

- 1. Mida el ancho de la puerta.**
- 2. Corte si es necesario.**
- 3. A lo largo del tope, coloque la tira corta en la moldura de manera que el vinilo quede firmemente en contacto con la puerta cuando esté cerrada.**
- 4. En los lados, coloque las tiras largas en la moldura de manera que el vinilo quede firmemente en contacto con la puerta cuando esté cerrada.**
- 5. Marque los agujeros, taladre y atornille en su lugar.**
- 6. Asegúrese que la tira corta quede bien ajustada entre las tiras largas.**
- 7. Los agujeros tienen rendijas para permitir ajuste.**