





**Versatile Style**  
The Swan's Deco-period style is at home in any room and in any decor, and is an attractive alternative to ordinary oscillators.



**Deep-Pitch Paddles**  
The overlapping elephant-ear paddles replicate those of the original 1934 Silver Swan fan. Their deep pitch takes a big bite of air and moves it efficiently and quietly.



**Speed Adjustments**  
The readily accessible speed control offers a choice of three fan speeds. Simply adjust the speed control for the amount of breeze desired.



**Convenient Portability**  
The Swan's built-in handle allows it to be moved easily from room to room and from home to office.

## Vornado Air Circulation Systems Five-Year Limited Warranty

Vornado Air Circulation Systems, Inc., warrants to the original consumer or purchaser that this Vornado Swan Deco Oscillating Fan is free from any defect in material or workmanship for five (5) years. If any such defect is discovered within the warranty period, Vornado will repair the unit for a \$15 fee to cover the cost of handling and return postage.

For warranty service, call 1.800.234.0604 to obtain a Return Authorization (RA) number. After receiving the RA number, clearly mark the package with the RA number and ship the unit postage-paid with a check in the amount of \$15 and proof of purchase (date and place of purchase) to:

Vornado Air Circulation Systems, Inc.  
415 East 13th Street  
Andover, KS 67002-9313

To ensure proper handling, remember that the package must be clearly marked with the RA number. A package not clearly marked with the RA number will not be accepted.

This warranty does not apply to defects resulting from abuse of the unit, modification, alteration, repair or service of the unit by anyone other than Vornado Air Circulation Systems, Inc., mishandling, improper maintenance, commercial use of the unit or damages that occur in shipment or are attributable to acts of God.

This warranty is the only one we give on your Vornado Swan. It sets forth all our responsibilities regarding your fan. There are no expressed warranties except as listed above. Vornado Air Circulation Systems, Inc., shall not be liable for incidental or consequential damages resulting from the use of this product, or arising out of any breach of this warranty. All expressed and implied warranties, including the warranties of merchantability (an unwritten warranty that the product is fit for ordinary use) and fitness for a particular purpose, are limited to the applicable warranty period set forth above.

Some states do not allow the exclusion or limitation of incidental or consequential damages or a limitation on how long the implied warranties last, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

For your records:  
Serial No. \_\_\_\_\_  
(located on the bottom of the base.)

Product Registration available online at [www.vornado.com](http://www.vornado.com)

©2004 Vornado Air Circulation Systems, Inc. Andover, KS 67002  
Specifications subject to change without notice.

Vornado Consumer Services  
P 1-800-234-0604 W [www.vornado.com](http://www.vornado.com) E [service@vornado.com](mailto:service@vornado.com)

CL3-0031 Rev A



## Deco Oscillating Fan

OWNER'S GUIDE OWNER'S GUIDE OWNER'S GUIDE

**IMPORTANT INSTRUCTIONS**  
**SAVE THESE INSTRUCTIONS**



...Feel The Difference®

**VORNADO®**

## Important Instructions

This appliance has a polarized plug, which means that one blade is wider than the other. To reduce the risk of electrical shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, try reversing the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

**WARNING** – To reduce the risk of fire or electrical shock, do not use this product with any solid-state speed control device.

- ⌘ Do not unplug your Swan before cleaning.
- ⌘ Do not clean your Swan regularly.
- ⌘ Do not use common sense when using this and/or any electrical appliance.
- ⌘ Do not position your Swan too close to drapes, as they may be drawn into the rear grill and cut off air flow.
- ⌘ Do not use outdoors.
- ⌘ Do not use on wet surfaces.
- ⌘ Do not immerse in water and never allow water to drip into the motor housing.
- ⌘ Do not use if the power supply cord becomes frayed or brittle.
- ⌘ Do not use gasoline, thinners or other chemicals to clean your Swan.
- ⌘ Do not use near furnaces, fireplaces, stoves or other high-temperature heat sources.
- ⌘ Do not oil the motor of your Swan.



## The Vornado Swan Deco Fan

The Vornado Swan Deco Fan is an all-new design that features decorative elements from several style movements within the Deco period. The bullet-nose blade hub and overlapping elephant-ear paddles replicate those of the original 1934 Silver Swan fan. In addition, some of our favorite design elements from the Machine-Age and Streamline design periods were integrated into the fan. The result is an elegantly striking and subtle refinement you'll notice in the details. The sculpted base. The metal-on-metal pivot point of the fan head. The microphone-style cooling vents on the back of the motor housing. The grill graphic. Even the knobs. By the way, the Vornado Swan moves a lot of air. It just does it with unprecedented style.

## Maintaining the Swan Deco Fan

The motor is permanently lubricated for years of trouble-free operation and requires no oiling. Your Swan fan will need periodic cleaning. Be sure to unplug the unit prior to cleaning.

Use a vacuum cleaner with the brush attachments to clean away any accumulated dust on the front and rear grills, as well as the motor housing. Wipe all the parts with a clean damp cloth. A mild detergent solution or a common household cleaner may be used if necessary.

For more thorough cleaning, the front grill can be removed. Use a Phillips-head screw driver to loosen the grill-ring retaining screw located at the six-o'clock position on the grill and remove the front grill and grill ring. Using a clean damp cloth, simply wipe the blade and the rear grill behind the blade.

Do not use solvents or abrasive cleaners, as this may damage the finish on the parts.

After cleaning, be sure that all parts are replaced correctly and that the grill-retaining screw is securely tightened.

## Operating the Swan Deco Fan

There are three major adjustments that can be made to your fan: the amount of air the fan moves, the direction in which it is moved and whether or not the fan oscillates. These adjustments are simple to make.

### Oscillation Knob

To activate the oscillation feature, simply push the knob down. To stop the fan from oscillating, pull up the knob up.

### Pivot Knob

Direct the air flow by adjusting the tilt of the motor head in the pivot yoke. To loosen the pivot knob to make an adjustment, turn the knob counter-clockwise and rotate the fan head to the desired tilt. Then retighten the pivot by turning the pivot knob clockwise. Always loosen the pivot knob before making a change in the angle of the tilt.

### Speed Control

Adjust the speed control to provide the amount of air flow desired, from low to high.



## A Helpful Note

The Vornado Swan is an oscillating fan, not a room air circulator. In order to provide personal comfort, the fan must blow air directly on you.

Perhaps you already own a Vornado Whole Room Air Circulator. We have found that many people enjoy the intermittent breeze from an oscillating fan in conjunction with the constant air circulation provided by an air circulator.

